



NASA Aeronautics Research Institute

In-situ Production of High Energy Nano- Fuels by Laser Ablation

F. Dynys(NASA), G. Mittal(U. of Akron) & A. Sehirlioglu(CWRU)

NASA Aeronautics Research Mission Directorate (ARMD)

FY12 Seedling Phase I Technical Seminar

July 9-11, 2013




Nano-Fuels

NASA Aeronautics Research Institute

Nano-Fuel → Liquid Hydrocarbon Fuel + Metallic Nano-particle

Metals – Energy Carriers
Oxidation Reaction



Potential Benefits

- Enhance Energy Density
- Enhance Burn Rates
- Reduce Ignition Delay
- Reduce Green-house gas emissions
- Enhance thermal Conductivity-Cooling
- Reduce Electrical Resistivity-Static Dissipater

Old Concept – Failed because of large metallic particles – incomplete particle combustion & rapid particle separation from fuel.

Nano-particle Advantage:

- Enhance fuel-to-oxidizer contact.
- Reduces the diffusion distance for rapid oxidation.




Nano-Particles

NASA Aeronautics Research Institute

Metallic nano-powders are commercially available:

- Particles are passivated to reduce fire/explosion potential.
- Nano-powders are agglomerated and difficult to disperse into stable suspensions.



Inactive surface oxide layer decreases energy density

Approach – In-situ synthesis of metallic nano-particles in the fuel by laser ablation. Stable suspensions of metallic nano-particles have been reported. Potential to engineer the particle surface chemistry by process control.




Laser Ablation

NASA Aeronautics Research Institute

- All materials have an ablation threshold (minimum peak intensity for remove material).
- Pulse lasers deliver high power densities – 10^8 to 10^{13} W/cm²

Pulse $\geq 10^{-9}$ s




Time
Long Pulse

Pulse $\leq 10^{-12}$ s






Time
Short Pulse

Non-equilibrium Plasma



- Temp. $\sim 10^4$ K
- Pressure > 1 GPa
- Rapid cooling
- Metastable Phases



NP Formation


- Nucleation/Growth
- Molten Droplet

Reaction with Fuel



Laser Ablation

NASA Aeronautics Research Institute





Experimental

NASA Aeronautics Research Institute

Laser – Excimer

- Wavelength – 248/351 nm
- Energy – 1.2/0.4 J
- Pulse Frequency – 1-50 Hz
- Pulse Width – 20 ns



Fuels – Butanol, Kerosene

Process Parameters

- Wavelength
- Energy Density(J/cm²)
- Pulse Frequency
- Surfactants
- Fuel Depth above Target
- Rotation Speed

Surface Chemistry

- Cathodic surfactant- CTAB-(C₁₆H₃₃)N(CH₃)₃Br
- Anionic surfactant-SDS-CH₃(CH₂)₁₁OSO₃Na
- Non-ionic surfactant- Span 80-C₂₄H₄₄O₆
- Poly Acrylic Acid- PAA-(C₃H₄O₂)_n






Particle Size Analysis

NASA Aeronautics Research Institute

- A) Electron Microscopy – Direct Measurement
- B) Dynamic Light Scattering – Indirect Measurement

Dynamic Light Scattering




Particle size information is obtained from intensity of the scattering pattern at various angles.

DLS measures Brownian motion and relates this to the size of the particles.

Stoke-Einstein
$$d = \frac{k_B T}{6\pi\eta D}$$

The diffusion coefficient(D) will depend not only on the size of the particle core, but also on any surface structure, as well as the concentration and type of ions in the medium.




Hydrodynamic Diameter




Laser Parameters

NASA Aeronautics Research Institute


20 Hz-Fe @ 248 nm




8 Hz-Fe @ 248 nm



2 Hz-Fe @ 248 nm



20 Hz-Fe @ 351 nm







Fe Particle Size

NASA Aeronautics Research Institute


No Surfactant




20 Hz-18 KV @ 351 nm



0.001 M PAA



20 Hz-18KV @ 351 nm







Al Particle Size

NASA Aeronautics Research Institute



0.1 M Span 80




20 Hz-18KV @ 351 nm



0.001 M PAA



20 Hz-18KV @ 351 nm







Aluminum

NASA Aeronautics Research Institute

20 Hz-Al-18KV @ 351 nm




20 Hz-Al-18KV @ 351 nm




Ablation Rate – 1 mg/hr – 0.001 M SDS

Target Surface



Ablated

Non-Ablated



Al/butanol suspension
destabilizes after 3-4 wks

Electrical Resistivity

Butanol – 1.6×10^7 W-cm


0.02 v% - 1.0×10^6 W-cm – No Surfactant




Iron

NASA Aeronautics Research Institute

20 Hz-Fe-18KV @ 351 nm



20 Hz-Fe-18KV @ 351 nm




Target wt. loss erratic
Carbon deposition - coking

Target Surface



Stable Fe/butanol
suspensions – 8 mos



Ablated

Non-Ablated

Electrical Resistivity

Butanol – $1.6 \times 10^7 \Omega\text{-cm}$


0.02 v% - $1.8 \times 10^6 \Omega\text{-cm}$ – No Surfactant




Boron

NASA Aeronautics Research Institute

20 Hz-18 KV @ 351 nm



Target Surface



Ablation Rate – 40 mg/hr – Shockwave Ablation

Suspension Stability – rapid sedimentation



Combustion Experiments

NASA Aeronautics Research Institute

Suspended Droplet Ignition



- Burning rate
- Burning behavior
- Mode of combustion

Hot Plate Droplet Ignition

- Minimum Ignition temperature

Energy Density Measurement

- Calorimetry



800 °C Capability

Nano-Fuel Preparation - Baseline



1. Commercial Powders
 - Al – 40 nm
 - Fe – 70 nm
2. 0.5 Wt. % Span 80
3. Butanol

Fe suspensions – rapid sedimentation



Burning Behavior Butanol

NASA Aeronautics Research Institute




Follows D^2 Law



Burning Behavior

Butanol + 0.02 v% Al (laser ablated)

NASA Aeronautics Research Institute




Steady Flame

Steady Flame

Particle Streaks

Intense Disruption




- Particles burn simultaneously with butanol



Burning Behavior

Butanol + 1 v% Al + 0.5 w% Span 80

NASA Aeronautics Research Institute




Steady Flame

Particle Streaks

Intense Disruption

Clear Bead Near End




- Strong disruption
- Droplet expands and contracts
- Particles burn simultaneously with butanol leaving bead without residue
- Simultaneous burning – increased rate of energy release, better combustion



Burning Behavior

Butanol + 2.5 v% Al + 0.5 w% Span 80

NASA Aeronautics Research Institute




Steady Flame

Particle Streaks

Steady Flame

Al Burning on Bead




- Al burns on bead as agglomerate after butanol combustion



Burning Behavior

Butanol + 5 v% Fe + 0.5 w% Span 80

NASA Aeronautics Research Institute



- Particle streaks and disruption start early
- Particles burn simultaneously with butanol leaving bead without residue
- Decreased soot luminosity



Ignition/Calorimetry

NASA Aeronautics Research Institute

Minimum Ignition Temperature-Droplets

- Butanol (690 °C)
- Butanol + 2.5 v% Al (660 °C)

Lower temperatures – No droplet burning

- Al agglomerate left after butanol evaporation burnt even at temperature as low as 370 °C

Calorimetry Results

- Butanol – 29.89 MJ/L
- Butanol+ 1 v% Al – 30.33 MJ/L
- Butanol + 2.5 v% Al – 31.24 MJ/L



Phase II

1. Increase Ablation Rate – g/hr scale
 - a) Pico-second laser – 1064, 532 & 355 nm
 - b) New Cell Design – liquid flow – cavitation bubbles
 - c) Organic-metallic chemistry – ferrocene - $[(\text{Fe}(\text{C}_5\text{H}_5)_2)]$
2. Suspension Stability - >6 mos
3. Nano-particle Characterization – chemical & physical properties
4. Combustion
 - a) Smaller droplet size – 50-200 μm
 - b) Combustion in radiative environment
 - c) Evaporation rate
 - d) Burning rate
 - e) Burning behavior
 - f) Completeness of metal combustion